


Label Printer

TSC MH241T

This tutorial shows how to load the toner and labels. If you experience issues printing, please contact me & do not change any settings!


Opening the printer



side view of printer with printer head closed

- 1) flip green lever down
- 2) flip green lever down (printer head will open)

Loading the labels




side view of printer with printer head open

with open printer head

- 1) load label roll (tips/spikes should show to you)
- 2) guide the labels below the metal bar

Loading the labels




front view of printer with print head open

with open printer head

- 1) tips/spikes should be below the metal guide rail
- 2) the triangle should point to the middle of the hole in the label

if you are only changing the labels, jump to “closing the printer”

Loading the toner




side view of printer with printer head open

with open printer head

- 1) load toner roll & keep the cardboard core of the old roll!
- 2) guide the toner below the metal bar
- 3) guide the toner between the printer head and labels (the matte side of the toner should face the labels/you if you look from the front)
- 4) roll up the toner onto the receiver cylinder by hand

Closing the printer



side view of printer with printer head open

- 1) gently but firmly push down the printer head (with fingers push the whole metal printer head down, until it clicks)
- 2) put green lever up
- 3) close the hood

More Resources

[Video: Printing stick-in labels on the thermal transfer printer TSC MB240T](#)

[order more toner](#) (110 mm, core 25 mm)

[order more stick-in-labels](#) (25.4 x 1200 mm, core 76 mm, 350 μ) → use with “stick-in-labels(25x120mm)” template in CASSbase